

User's manual

CONTENT

1. NORMAL FUNCTION INTRODUCTION.....	3
1.1 DIAL PHONE NUMBER.....	3
1.1.1 Dial Domestic Phone Number.....	3
1.1.2 Dial Fixed Extension Phone Number:.....	3
1.1.3 Dial International Call Number:.....	3
1.1.4 Dial phone in call list.....	3
1.1.5 Emergency Call.....	4
1.6 FUNCTION MENU.....	4
1.6.1 Selection by Rolling Direction Keys.....	4
1.6.2 Exit Menu.....	4
2. STRUCTURE OF FUNCTION MENU.....	4
2.1 DEFAULT STRUCTURE OF FUNCTION MENU.....	4
2.1 File Manager.....	4
2.2 Phonebook.....	5
2.3 Fun& game.....	5
2.3.1 Games.....	5
2.3.2 JAVA.....	5
2.4 CALL CENTER.....	5
2.4.1 Call History.....	5
2.4.2 Call Settings.....	6
2.5 MESSAGES.....	6
2.5.1 SMS.....	7
2.5.2 MMS.....	8
2.5.3 Voicemail server.....	9
2.5.4 Broadcast message.....	9
2.6 Multimedia.....	9
2.6.1ATV.....	9
2.6.2Camera.....	9
2.6.3 Image viewer.....	10
2.6.4 Video Recorder.....	10
2.6.5 Video Player.....	10
2.6.6 Audio Player.....	11
2.6.7 Sound recorder.....	11
2.6.8 FM Radio.....	11
2.7 Organizer.....	11
2.7.1 Calendar.....	11
2.7.2 Tasks.....	11
2.7.3 Alarm.....	11
2.7.4 World clock.....	12
2.8 Settings.....	12
2.8.1 Dual SIM settings.....	12
2.8.2 Pen calibration.....	12
2.8.3 Phone Setting.....	12
2.8.4 Network settings.....	12
2.8.5 Security settings.....	12
2.8.6 Connectivity.....	13

Bluetooth	13
2.8.7 Restore factory settings	14
2.9 User Profiles	14
2.10 Extra	14
2.10.1 Calculator	14
2.10.2 Currency converter	14
2.10.3 Stopwatch	15
2.10.4 Ebook reader	15
2.11 Service	15
2.11.1 Internet service	15
2.11.2 Accounting data	15
2.12 Shortcuts	15
3. STATEMENT	15

1. Normal Function Introduction

1.1 Dial Phone Number

When the network supplier's signs appear on the screen, you can call or answer the telephone. The information bar on the upper left corner of the screen shows the network signal strength. (there are five information bars means that the strongest signal) Call quality is impacted more by the barrier, and so your handset is moved in a small area, as will be able to effectively improve the call quality.

1.1.1 Dial Domestic Phone Number

Input telephone numbers with the numeric key and then press dial key to begin calling. If you need to change the telephone numbers, please press the right soft key to delete characters. The screen will display the called animation while dialing. After the other side picks up, the screen will show the called status information, and if you open the tone, there will be a tone (be subjected to network support).

After the call ends, press the hang up key to hang up.

Zone number + Phone number + Dialing Key

1.1.2 Dial Fixed Extension Phone Number:

Some fixed extension cannot be directly called; you need to first get through the telephone exchange and then dial the extension. When you input the phone number, insert the symbol "P" between the telephone exchange number and the extension number, the phone will complete all your dial-up, automatically dial the extension. The method of inputting "P" is to long press * key (here symbol "P" is displayed on the screen).

Zone number + Telephone exchange number + P + Extension number + Dial key

In standby status, input zone number (if you want to dial long distance call) and telephone number, then press "dial" key, if you want to dial the extension number, please input: the telephone exchange number + P + extension number or exchange number + W + extension number, and it will auto dial the extension number. Long press "*" key, you can input "P", short press "*" two times, and you can input "W", P indicate pause 3 seconds then auto dial extension number, W indicate that you must press dial key to confirm the extension number.

Note: press the right soft key to delete the last input letter; long press to delete all.

1.1.3 Dial International Call Number:

To make an international call, you cannot long press * key until the prefix symbol "+" of the international long-distance telephone number is displayed. This will allow you to dial any national telephone call even if you do not know the prefix of the local international telephone number (for example, it is 00 for China).

Input the prefix and then input the country code and the whole phone number you want to call. Country code complies with the usual practice, Germany 49, Britain 44, Sweden 46 and so on.

"0" ahead of the city code should be removed when dialing, as is the same as to call a usual international telephone.

For example, to call a hotline from other countries, you should dial:

+86 21 114

+ Country code + Whole phone number + Dial key

1.1.4 Dial phone in call list

The numbers you dialed out and received are all saved in a list in your phone, recent dialed and received number showed in the first. Every number is classified by dialed, received and missed; the phone provides all number items for you to view all

number records. When the number list storage is full, the old number will be deleted automatically. If you want to view the list, you must do the key operations as below:

View dialed number, press dial key.

All the number stored in the number list can be dial out by pressing the dial key.

The number list shown, you can press confirm to view the details, entering the option, press save you can directly save the number into phonebook.

1.1.5 Emergency Call

If you stand within the network coverage (to check the indication bar about the network signal intensity on the upper left corner of the screen), you should be able to call for the emergency service (even in the absence of SIM card, you can call for emergency). If your network suppliers don't have provided roaming services in the region, the screen will show "Only for EMERGENCY", indicating you can only do such a call.

1.1.5.1 Answering call

Under normal mode, when there are calls via press answer key to answer. If any key answering is set to open, can press any key and answer a call. If a headphone has inserted, you can also use the headset button for the call.

1.1.5.2 Call Record

Your phone can store recent call record and all call time since you use the phone.

1.1.5.3 Menu in Calling

In calling case, press option key and then enter calling menu. The operation methods of calling menu and function menu are the same.

This call can only be seen during the course of calling, and functions such as call waiting, call hold, multi-conference need the support of network, please contact your network supplier.

In calling menu, you can implement the operations.

*Note: some menu options only happen under some specific circumstances. Such as: "Switch" only happens when there exists the calling and pending call at the same time.

1.6 Function Menu

The function of each menu.

1.6.1 Selection by Rolling Direction Keys

In standby status, click to enter main menu, or press middle navigation key to enter main function menu.

In all main menu or submenu, press up/down key to roll to the function needed, and press left soft key to enter the function option, right soft key to return current menu.

1.6.2 Exit Menu

In function menu, normally, you can press right soft key to exit a menu. Press hang up key return to standby interface.

2. Structure of Function Menu

2.1 Default Structure of Function Menu

Note: some menu only displayed in some special conditions.

2.1 File Manager

Insert memo card, in the menu, you can create new folder to manage your data, store different files, such as music, picture etc. enter file management interface, separately list the total capacity and capacity of memory available, enter option

interface can see the options below:

Open/Create new file folder/Rename/Delete: Sorting

Function parameters as below:

Function	illustration	Optional	path
Ring file	MID/WAV /AMR	default	Audio folder
MP3 file	MP3	default	My Music folder
Picture file	BMP/GIF/JPG	Default	Photos folder
Video file	3GP/MP4	Default	Video folder
Electronic book	TXT	default	E-book folder

2.2 Phonebook

You can use phonebook to store the important message such as name, mobile number, family number, company number etc. choose phonebook from main menu or press right soft key in standby interface, you can enter phonebook function.

Note: the phone can store 1000 numbers.

In phonebook you can view quick search, search contact, add contact, copy all, delete, incoming call group, other numbers, setup, full screen caller, incoming call ring, ten options.

2.3 Fun& game

2.3.1 Games

In games interface, every game has items such as new game, game mode, game rank and game help:

If the last time the game hasn't over, then the next time you enter the game, you can continue to play.

Game setup:

You can open or close the background music, sound effect and vibration.

2.3.2 JAVA

Install JAVA

Java provides you many kinds of games and network application program, select a Java program in Java program list, click "option", the menu has carry, setting and message reference. Select carry, it will start Java program(if select the network application program, it will displays a window that if it is permitted to carry the program, select "yes" to enter the program), after entering the Java program, consult the system indication to run the program. (to run the network program must pay the fee for entering network).

JAVA Setup

You can set Java sound effect, Java background light, Java vibration, select SIM card, Java SIM card 1 setting group, Java SIM card 2 setting group, storage setting.

JAVA default safety

Can set the third part, distrust range and range option.

2.4 Call center

2.4.1 Call History

In the menu it has the SIM card 1 call records and SIM card 2 call records.

The operation is the same.

2.4.2 Call Settings

There are SIM card 1 call setup and SIM card 2 setup in the menu. The two operations are the same, as below:
Call setting

The phone number: the system default value is used for whether to send the number. Press up/down navigation key to select system default, hide number or send number.

Call Waiting: open or close Call Waiting. Choose Inquiry and view the current status of Call Waiting.

Call diverts:

- Divert all voice calls: open the unconditional transfer and any dialing call will be transferred to your set number under no circumstances.
- Divert if unreachable: after not contact transfer is opened, under the circumstances where the other side will not contact you, transfer the dialing call to your set number.
- Divert if no answer: after transfer without answer is opened, under the circumstances where your handset has no answer, transfer the dialing call to your set number.
- Divert if busy: after transfer when busy is opened, when your handset is busy, transfer the dialing call to your set number.
- Divert all data calls: when calls are the data calls, forwarding.
- Cancel all divert: cancel all Call forwarding.
- Call barring: restrict the dialing calls.
- Outgoing calls:

All call: restrict dial all calls, except emergency calls.

International call: restrict international calls.

International except national call: you can call at the host country or call to the national (that is, ownership of the network provider of the host country) abroad. For detail, ask the network provider for help.

Incoming calls:

Restrict all the incoming calls.

Restrict roaming calls

Cancel all: cancel the set restriction (input the PIN2 code).

Change barring password: change the Password.

Line switching: choose Line 1 or Line 2.

Advance settings

Blacklist: Set the blacklist numbers first, then you can choose on/off the mode to enter this function.

Auto redial: To set this option on or off to activate the function or deactivate. Setting On will redial 10 times while busy or unreachable until you call is answered or you press the hang up key or cancel

IP dial: The device support IP dial function and you can edit up to three IP number. In the Phone Book List menu, select a number, press the "Option" and select IP dial, and the phone will add the IP number before it and dial.

Call time display: To set the option On/Off to activate the function.

Call time reminder: You can set a reminder for a certain call time.

Auto quick end: You can restrict the call time.

2.5 Messages

Select 'message' menu enter submenu.

If network supports, and you have applied the service to the network supplier, through the message center, you can receive Chinese, English SMS and multimedia

message.

2.5.1 SMS

Write message

Make sure that you have set the message center number rightly before writing message.

Enter the sub-menu and edit SMS, click the left soft key to enter "option" menu:

- ✓ Send to: To send the message to your desired phone number.
- ✓ Input method: To change the current input method.
- ✓ Insert template: Insert the preset template in the SMS.
- ✓ Advanced: You can insert object, insert number, insert name, insert bookmark, or set the text format.
- ✓ Save to Draft: after editing, if you don't want to send, you can save it in draft box.

Finished, press confirm, you can send it by pressing roll key to select send, save and send, save, multi-send or group send, the SMS will send to other mobile phone.

Inbox

Enter submenu inbox view received SMS; inbox is divided into SIM card 1 and SIM card 2 inbox. The operations of two inbox are the same.

When viewing the message list in inbox, it will displays the receive date and time, and the name of other side or number (when the number is in the phonebook)

Viewing message list, you can use up/down roll key to select last or next message.

When the SMS list is shown in inbox, you can press confirm to read the detail content. Then press option to operate as below:

- Reply: send a SMS to the current SMS sender.
- Call sender: Call the sender
- Forward: Forward the SMS to other contacts.
- Delete: delete the current SMS.
- Delete all: Delete all SMS in current SIM card.
- Advanced: This menu has seven sub items,

Use number: pick up the phone number of the sender who sent the SMS, and you can dial it dial-up or save it in Phonebook.

Use URL: link the bookmark URL in SMS.

Use USSD: If current network supports the function, it can enter Unstructured Supplementary Services Data function.

Copy to phone: if this message is stored in mobile phone, copy it to SIM card. If the message is stored in SIM card, copy it to mobile phone.

Move to phone: if this message is stored in mobile phone, moves it to SIM card. If this message is stored in SIM card, moves it to mobile phone.

Copy all: if this message is stored in mobile phone, copy it to SIM card. If the message is stored in SIM card, copy it to mobile phone.

Move all: if this message is stored in mobile phone, moves it to SIM card. If this message is stored in SIM card, moves it to mobile phone.

Outbox

Enter outbox to view the saved SMS; outbox divided into SIM card 1 and SIM card 2 outbox, they have the same operation method.

Drafts

Enter draft box to view the saved SMS that haven't sent.

Templates

Some commonly used phrases can be stored in Common Phrase to avoid the duplication of each enter while sending SMS. After it is finished, choose Edit or Delete.

SMS settings

When using SMS function, you need to do the necessary settings at first.

- ✓ Profile settings: choose a suitable mode for your SMS. Enter the corresponding names, SMS center number, period of validity and SMS format settings of all modes.
- ✓ Common settings: set whether to open the message report or return path.
- ✓ Memory status: view the storage space of SIM card or handset mailboxes.
- ✓ Preferred Storage: choose your handset or SIM card.

Set SMS center number: please contact with your network provider, to obtain the SMS center number.

State report: if you set state report open, when the other side receive your SMS or because of some reason can't receive, the center will send back the state report, you can easily know if other side has received your message.

*note: this function needs the support of network service provider.

2.5.2 MMS

Write message

Create a new multimedia message. You need to fill the contents of receiver, copy, Encryption copy, subject, edit.

Inbox

View received multimedia message. (The same operation as SMS inbox)

Play: view the current content of the multimedia message.

Answer: to answer the current sender in the multimedia message.

Detail information: lookup the detail current information of the multimedia message.

Transmit: edit the relative information of the current multimedia message, transmit the current multimedia message.

Save picture: save current picture of MMS.

Save music: save current music of MMS.

Pickup number: pickup the number of sender.

Delete: delete current multimedia message

Outbox

Outbox store the multimedia message when sent out not succeed. (the same operation as SMS outbox)

Transmit: send current multimedia message to other receiver.

Play: play the current content of the multimedia message.

Detail information: lookup the detail current information of the multimedia message.

Delete: delete current message.

Draft box: after editing, if you don't want to send, you can save it in draft box.

View: view current MMS.

Send: send current multimedia message.

Edit: can re-edit current multimedia message.

Delete: delete current MMS

Delete all: delete all the parts in draft box.

Save as template: save current multimedia message as template

Use item: select the number in multimedia message to dial or save.

Drafts

Save the MMS selected to save when send it.

Templates

There are preset MMS and MMS user creating in mobile phone.

2.5.3 Voicemail server

The functions of voice mail box are as follows:

Edit: set name and phone number.

Connect to voice: connect to voice mail box by dialing.

2.5.4 Broadcast message

This menu includes SIM1 broadcast message and SIM2 broadcast message. All the operations are same.

■ Receive Mode: to switch on/off the broadcasting function.

■ Read Message: to select the menu to access to the broadcasting message you ordered.

■ Language: to select the language for broadcasting.

■ Channel Setting: to select the channel for broadcasting

Attention: the broadcasting and voice mail box functions are provided by network service provider. Please contact your service provider for detail.

2.6 Multimedia

2.6.1 ATV

Analog TV can search the TV channels via outside antenna, it will make you more freely to receive TV program.

1. Channel list: after searching TV channel.

2. Manual search: can manual input TV channel.

3. My channel: can add my favorite channel to my channel from the channel list.

4. Channel search: before watching TV, you must search channel first, then the channels can displayed normally and you can change channel.

5. Search region: this option can select the region for channel searching, in order to better search the local programs.

2.6.2 Camera

Camera functions is the part that can exert your artistic talent, the manual functional settings allow you to fully enjoy the pleasure of a digital camera, high-quality camera and a rich feature set to ensure that your creativity to show perfect. In the multi-media, select the camera into the camera functions:

Following configuration options:

1. Album: see 5.6.1

2. Camera setting: can set light compensation, shutter sound, Exposure compensation, avoid flash, delay capture, continuous shot.

3. Photo setting: Can set five size: 240*320, 80*60, 160*120, 320*240, 640*480. The quality of photo can be set to low, middle and high.

4. White Balance: White Balance can set according to the environment auto, sunlight, lamp, fluorescent lamp, cloudy, incandescent light.

5. Profile: Provide auto and night mode.

6. Effect setting: Provide different effect setting, it is normal, gray, ancient, ancient green, ancient blue, negative.

7. Photo frame: System default is no frame.

8. Store Path: Setup photographs default storage path

9. Return default: Restore the setup to the default.

Note: 1. In capture status, short cut 1-7 corresponding the setting upside.

2. the handset has double cameras, one on the front of camera, the other on

the background.

2.6.3 Image viewer

Select Image Viewer to open the album and look the photos.

Press Option to go into:

View: to look the picture which you select

Browse Style: to select the display style such as list or matrix

Forward: forward the file to phonebook, screen saver, power on/off display

Rename: to rename the files

Delete: to delete the selected files

Delete All Files: to delete all saved files

Sort: to set the logic for sorting

Storage: to select the pass to store or to read, either from mobile phone or from

SIM card

2.6.4 Video Recorder

The mobile phone provide record function, it is also the part that can exert your talent, the manual functional settings allow you to fully enjoy the pleasure of a digital camera, high-quality camera and a rich feature set to ensure that your creativity to show perfect. In the multi-media, select the video recorder to the record functions, in preview interface press OK key to start record, press OK again or right soft key to finish, system auto save, then enter preview status.

There are settings in options below:

■ Recorder Setup

Can set White Balance, Exposure compensation, night shot, avoid flash one by one.

White Balance can set according to the environment auto, sunlight, lamp, fluorescent lamp, cloudy, incandescent light

■ Film setting

Set video quality.

■ Effect setting

Provide different effect setting, it is normal, gray, ancient, ancient green, ancient blue, negative.

■ Store Path

Set storage path to phone or T-flash card.

■ Restore default

Restore all setup to the default.

2.6.5 Video Player

The menu enable you to play, transmit, rename, delete and sort the 3GP or MP4 film stored in handset. Select film player then press confirm, you can view all films stored, press up/down direction key to select last or next film, press option key enter option menu, also can click screen to enter the option interface wanted.

Options as below:

■ Play : Enter play film interface, then press OK key. Film begins to play. This time can set full screen play, play speed etc by the shortcut key on screen.

■ Send: send the current video to the phonebook, open/close animation, Bluetooth etc.

■ Rename: Rename the currently film.

■ Delete: Delete the currently film.

■ Delete all files: Delete all the currently chosen films.

■ Sort by: array the order of films (by name, type, time, size)

■ Storage: choose the storage position of the file.

2.6.6 Audio Player

Choose music player and enter MP3 play interface. Up/down/left/right the four function keys act as stop/play/pause/select the last song/ select the next song, press left soft key to enter play list, you can scroll to search songs. In playlist interface, press left soft key again to enter music relative setting.

1. Play: play the currently chosen song.

2. Detail: View the detail of the song.

3. Add a ring: add the current song into the ring storage of profiles.

4. Update Song List: update song list.

5. Setup: Set the save path, auto made list, repeat, random, play

Background, stereo sound output via Bluetooth, stereo Bluetooth earphone, sound effects, display lyric.

2.6.7 Sound recorder

■ Select to record sound. Press Left soft key to select

■ Record: to record a new sound

■ Play: to play the selected file

■ Append: to add new extended part to the selected file

■ Rename: to rename the selected file

■ Delete: delete current file

■ Delete All: select all files

■ Settings: to set the parameters for sound record

■ Forward: forward current file to Mode

2.6.8 FM Radio

The handset supports FM radio, choose FM radio menu to enter, press 'OK' key can start. Operation as following:

Channel list: can edit channel, name shown on this list.

Manual input: directly input FM channel frequency

Auto search and setting: Auto search FM channel and auto update channel list.

Set: can set play background and output to the handset loudspeaker.

Record: can record the radio message.

Files list: enter Audio file folder.

2.7 Organizer

2.7.1 Calendar

Enter the agenda management sub-menu.

Press left and right keys to modify the date, and modify month by up and down keys. Press option and enter submenu.

Calendar: create a new schedule. And add an alarm clock reminder. You can choose one time, Daily, Customization, Every Week an Every Month five options.

✓ One time: the schedule is reminded for one time.

✓ Daily: the set hour daily is reminded.

✓ Customization: set the ringing hour of the alarm clock in a week.

✓ Weekly: the set hour weekly is reminded.

✓ Monthly: the set hour monthly is reminded.

Add item: add a new work.

Jump to the specified date: jump to the specified date from the current date.

Week view/month view: view exchange between week and month.

2.7.2 Tasks

Edit, delete, delete all, send schedule

2.7.3 Alarm

The phone can set five alarm clocks. Select one, you can edit and make setting.

2.7.4 World clock

Select world time in submenu, press left/right/up/down navigation key to switch between cities and time zone.

2.8 Settings

2.8.1 Dual SIM settings

Double cards open, only SIM card 1 open, only SIM card 2 open, flight mode.

2.8.2 Pen calibration

Calibrate the touch screen of the phone for better accuracy.

2.8.3 Phone Setting

- Time and date: set date and time
- Time Zone setup: set time zone of a city.
- Time /Date Setup: set the current time and date.
- Time format Setup: set the display format of time and date.
- Schedule power on/off: set time and open or close the handset within the set time.

Language: set the display language of handset menu.

Select input method: choose some input methods to use.

Pref. input methods: choose a default input method.

Color lamp setting: set color lamp open / close.

Preset coding: provide two codes for choose.

Display:

- Wallpaper: choose standby interface wallpaper.
- Screen saver: choose a screen protecting picture for the main screen in standby interface and set the wait time.
- Power on display: choose the animation picture for opening.
- Power off display: choose the animation picture for closing.
- Main menu style: choose the style for main menu.
- Show date and time: open or close the current display time in standby interface.

Greeting text: In standby interface open or Close greetings. Greetings Content can be edited.

Dedicated key: designate the quick enter menu via press direction keys in the standby interface.

Auto update of date and time: open or close auto update time.

UART settings: choose the SIM card 1 or 2 serial port.

3D Sensor: set the mode of 3D sensor.

Misc. settings: set the brightness and the delay time of LCD background light.

Touch screen vibration: you can on/off the vibration when you touch the screen.

Note: some function needs network supplier support.

2.8.4 Network settings

Network Setup

Network Selection:

Auto select: auto search the network of the SIM card.

Manual: search all available networks, manual login.

Preferential Network: Pre-save several networks you like.

2.8.5 Security settings

SIM 1 security settings:

1. The SIM card 1 Lock: you can set the safety option in this menu, prevent your handset or SIM card from being illegally used.
2. PIN Code: PIN Code can be used to prevent your SIM card from being illegally

used.

If the current PIN code has been closed, choose Open and start PIN code protection, and your PIN code will be required before your handset starts next; if the current PIN code has been opened, choose Close and close PIN code protection, and choose Change PIN code and set new PIN code; please input the old PIN code, new PIN code and repeat the new PIN code in order in accordance with the reminder.

* Note: if PIN code is input continuously incorrectly to three times, the SIM card will be locked, when, you need PUK code to unlock SIM card. PIN code and PUK code can be offered to you with SIM card, if not, please contact your network supplier. The default PIN code is generally 1234, and please change it to your own set password as soon as possible.

3. Fixed Dial-up:

When the function operates, the phone numbers in Fixed Dial-up table or of beginning with some certain digits can only be dialed. (Require SIM card support)

Mode: open or close Fixed Dial-up function (input PIN2 code).

Fixed Dialing List: input the phone number of Fixed Dial-up.

* Note: to open and close Fixed Dial-up function, it is necessary to input your PIN2 code. Please contact your network supplier to obtain PIN2 code. Open Fixed Dial-up and then enter the calling card which displays the numbers of Fixed Dial-up.

Restrict dialing: restrict dialing out.

Change Password: Change Password, including modifying PIN1 and PIN2 and phone password.

SIM 2 security settings: The setup operations consult the safety of the SIM card 1.

Phone Lock:

In order to prevent illegal usage, you can set password in your mobile phone. Once this function is chose, each time you power on your phone, you must input phone password, and you can unlock the phone only by this way, and then send or answer the call. Users can remove phone password, in this case, the phone cannot prevent illegal usage.

- Input the mobile phone password, use the right soft key to clean error input, and press confirm to finish it.

For example, if the password of mobile phone is set to be 1122, input 1122.

* The default password is '1122', please change the password to your own as quick as possible, suppose that you forgot your phone password, you must contact with your retailer or local authorized maintenance center to unlock your password. Auto keypad lock: To prevent unwanted key press, you can use this function to lock the keypad. If you do not carry out any operation in the present time, the keypad will be locked automatically.

Change password:

You can change the phone password.

* Note: part of functions is supported by your network supplier.

2.8.6 Connectivity

Bluetooth

There are many Bluetooth setting, often used in handset, PC, Bluetooth headset.

The phone supports every Bluetooth functions:

HSP (wireless headset dial/receive calls), A2DP/GAVDP (stereo music function). The two function used to Bluetooth headset, some Bluetooth headset only support HSP function. Some support both HSP、A2DP/GAVDP functions.

FTP (connect with other mobile phone to transmit files)

SPP (connect with PC to transmit files)

DUN (connects with PC, get on the internet via PC)

HFP (Vehicle features)

Specific menu is as follows:

- ✓ Power: open or close the Bluetooth function
- ✓ Visibility: Open this function, this phone can be searched by other Bluetooth equipment, close, this function; other Bluetooth cannot find this phone.
- ✓ My device: Already found device.
- ✓ Search audio device: search the equipment of Bluetooth that is searching opened Bluetooth headset. Include: HSP and A2DP/GAVDP.
- ✓ My name: Name of equipment of this phone: can be amended.
- ✓ Advanced:

Audio path: set sound route to transfer to earphone or remain in the phone.

Storage: To set shared directory and property.

Sharing permission: To set permission of sharing, you can choose full control or read only.

✓ My address: Show the address of current handset.

2.8.7 Restore factory settings

Set the functions of your phone to default settings: 1122

2.9 User Profiles

Startup: Choose Startup and enter the general environment.

Individual Setup: Choose Personal Setup and enter the general mode to customize. Function as below:

Ring settings: change the calls, alarm clock; open-close the phone, information and key sound.

Volume: here set the rings and the volume of keys.

Ring methods: select the ring, shaking, vibration and ring and ring after vibration several options.

Ringtones types: select one tone, continuous ring and gradual increase.

Reminder tones: open or close the alarm sound, errors, network linking sound and call linking these several sounds.

Response mode: any key can be set to receive this response mode.

Meeting, outdoor, indoor, operate it like the general profile.

Headset: When insert headset, it auto open the mode. Personal operate it like the general profile.

Bluetooth: When insert headset, it auto open the mode. Personal operate it like the general profile.

2.10 Extra

2.10.1 Calculator

Input the numbers to be calculated with numbers 0-9 and input decimal with # key.

Press the operator key on the screen to input the four operators +, -, x, ÷.

Press the Right Soft Key and remove the recent enter or results by digit, and press the right soft key "Exit" to exit from the calculator. Press the left soft key "Result" the calculated results.

* Note: The accuracy of the calculator is limited, as will generate rounding error, especially in addition to countless times.

2.10.2 Currency converter

Input the exchange rate before currency conversion, and then input the home or foreign currency values, after confirmation, and the value you need is shown in the other edit box.

2.10.3 Stopwatch

Use the function you can measure the last time, there are respective time count, circles time count and multi-side stopwatch.

2.10.4 EBook reader

Support TXT format files, can store in phone or the E-book file folder of T card

2.11 Service

2.11.1 Internet service

Your mobile phone support the service based on Wireless Application Protocol(WAP). You can visit the service that your network provider supports. The service will make you obtain the messages of news, Weather Forecast and Flights etc.

Note: GPRS service needs network supports, you must open and in the service area, it will be used.

✓ Front page: choose the front page; you can land in the front page. The front page is the WAP site you have set in the setting. If you have not yet set, use the site set in advance by the manufacturer.

✓ Bookmark: display exist bookmarks, select that can directly link to the web linked to the bookmark.

✓ Web history: under this submenu, list all the recent visit web record.

✓ Saved website: select the saved web pages to internet. Input website: under this submenu, input the URL site of the

WAP service.

✓ Service inbox: store the information from the service inbox. Setting: setting of browse relative content of the WAP service.

✓ Edit setting: the phone default GPRS.

✓ Browse option: set the parameter of browsing web; include waiting time and showing picture.

✓ Service information setting: open or close service information.

✓ Clear up cache: select this menu to clear up cache.

✓ Clear up personnel data: select this menu to clear up personnel

data.

✓ Credit credence: to check credit credence.

2.11.2 Accounting data

GSM data:

Select an account to enter.

2.12 Shortcuts

Function on the menu shortcut, enter operations directly

3. Statement

If the content described in this manual with your phone does not match, please subject to the phone.

The company has retained the right to revise the content of the manual without any advance notice.